

Quick Start Guide

MiniDV Camera - Canon ZR Series



Inserting the Tape

- 1 Slide OPEN/EJECT switch on bottom of camera and wait for the tape door to open
- 2 Insert MiniDV tape into compartment, push tape door closed, then shut cover



Getting Up and Running

- 3 Turn camera ON by pushing the small grey button on the POWER dial and rotating knob to "CAMERA"
- 4 Open LCD display on left side of camera to view your picture
- 5 Slide lens cover switch down on front of camera



Recording Video

- 6 Push the white button next to the POWER dial to start recording
- 7 Push the white button again to pause or resume recording
- 8 ZOOM in or out by adjusting the "W - T" zoom tab located on top of the camera



Playing Back Your Recording

- 9 Rotate the POWER dial knob to "PLAY"
- 10 Fast forward, rewind, play or pause by pressing and moving the **joystick** on the LCD screen
- 11 Turn camera off by rotating the POWER dial to the "OFF" position

